

CETOL® UV INTERIOR APPLICATION GUIDE

Working With Cetol® UV Interior

■ Preparation Procedures

New, Unfinished Wood

1. Clean the surface (if needed) with a solution of four ounces of 100% powdered Tri-Sodium Phosphate (TSP) or phosphate-free substitute in one gallon of warm water. Do not allow cleaning solution to dry on surface. Use a damp cloth or sponge to remove residue from the surface and allow to dry.
2. Sand the surface using 150-180 grit sandpaper. Always sand wood with the grain to achieve a smoother surface without sanding marks. Remove sanding dust by vacuuming, then wipe surface with a damp cloth to remove final dust particles.

Tips

- *Avoid direct sunlight, which may cause uneven color because of shortened open time and poor penetration.*
- *It is always recommended to perform a two-coat test sample on the wood.*

CETOL® UV INTERIOR APPLICATION GUIDE

■ Application Procedures

Smooth wood coverage: 450-550 sq. ft./U.S. gallon

New/Bare Wood

1. Follow the preparation procedures
2. Apply first coat of Cetol UV Interior
3. Let surface dry for minimum of two hours
4. Lightly sand with a fine scuffing pad or 220 grit sandpaper
5. Apply second coat of Cetol UV Interior
6. Clean tools with soap and water

CETOL[®] INTERIOR CLEAR APPLICATION GUIDE

■ Maintenance Procedures

The longevity of the coating system depends on many factors such as daily wear & tear and exposure to ultraviolet light. Simply apply a refresher coat of Cetol UV Interior when visually required by following the procedure below.

1. Follow preparation procedures using the cleaning solution, reducing it to two ounces of 100% powdered Tri-Sodium Phosphate or phosphate-free substitute.
2. Sand the project surface with 200 grit sandpaper. Remove sanding dust by vacuuming then wipe surface with a damp cloth to remove final dust particles.
3. Apply one coat of Cetol UV Interior.
4. Clean tools with soap and water.